



User's manual

Theaterspot Pro 650/1000 fresnel/antihalo



Table of content

- 1. Safety instructions..... 3
- 2. Applications..... 4
- 3. Function 4
 - Angle 4
- 4. Install or Change the lamp..... 4
 - Focus 4
- 5. Note 4
- 6. Technical parameter: 4

1. Safety instructions

FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature. Avoid exposing it to direct rays of the sun or near a heating appliance.

Not put it in a temperature below 41°F /5°C, or exceeding 95°F /35°C.

Keep away from humidity, water and dust

Do not place the set in a location with high humidity or lots of dust.

Containers with water should not be placed on the set.

Keep away from sources of hum and noise

Such as transformer motor, tuner, TV set and amplifier.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

If out of work, contact sales agency immediately

Any troubles arose, remove the power plug soon, and contact with an engineer for repairing, do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable

Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug. When not using the player for an extended period of time be sure to disconnect the plug from the receptacle.

2. Applications

Stage, TV station, theatre, exhibition, saloon, auditoria, gymnasium, etc.

3. Function

face light, top light, ear light or long distance soft light, centralized light, back light, side light, effect light, etc.

Angle

Can install in any angle

4. Install or Change the lamp

Make sure the power is off before install or change the lamp. Loose the 2-M4 safe screw with screwdriver. And then press down and go round the outside quincunx screw 90° to open the bottom cover. At last pull out the lamp and change the lamp vertically.

Focus

Loose the quincunx screw in the center of bottom cover and adjust focus from front to back. Please tighten the screw after adjusting.

5. Note

1. Lens, reflector, or lamp holder support with breakage should not be used any more. Cut off the power and change it.
2. Don't use the damaged protective net. Make sure the parts are very well before installation.
3. The damaged or deformed lamp should be changed promptly. Do not touch the bulb directly with hand. Use the alcoholic cloth to brush fingerprint.
4. Using the same model lamp to replace the used one.
5. Clean the light periodically.
6. Make sure the light is hung safely. Check firmware and screw periodically.
7. Please contact our factory if the magnetic base, socket or plug is oxygenated (black oxygenation). Can be used only after changing.
8. The groundwire should touch the earth when installing the light.
9. Qualified personnel carry out installation, repairs, and maintenance.

6. Technical parameter:

Model: A/B- 1000PC/AN/FR

Power supply: AC220V±10%/50-60Hz

Light sources: Tungsten Halogen 220V 650W/ 1000W GX9.5

Size: 370mm×270mm×220mm

★ Weight: 5.8 Kg

Importeur:

B & K Braun GmbH

Industriestraße 1

D-76307 Karlsbad

www.bkbraun.com

info@bkbraun.com

